

Please read the following instructions carefully as it contains important information concerning the use and maintenance of your unit.

USER GUIDE

- Always use the correct ice packs as recommended by Minus40
- Fill ice pack with tap water up to the fill line
- Ensure that ice pack caps are correctly tightened to prevent leakage
- Always load ice packs, cool packs and warm packs in accordance with the manufacturer's recommendation.
- Follow the packing instruction on the Lid interior for vaccine, ice packs, cool packs and warm packs.
- Always place the foam sheet on top of the ice packs and ensure that the lid is closed tightly.

MAINTENANCE INSTRUCTIONS

- Never expose the cold box to direct sun light for long periods.
- Keep internal and external surface of the cold box dry and clean when it is not in use
- Keep all metal parts coated with a thin film of oil when not in use
- Always load ice packs, cool packs and warm packs in accordance with the manufacturer's recommendation.
- Over a period of time if any fixture (e.g. hinge rod, locks & handles) loosens, it should be tightened immediately.

Lees die volgende instruksies aandagtig deur aangesien dit belangrike inligting bevat oor die gebruik en instandhouding van u eenheid.

VERBRUIKERS HANDLEIDING

- Gebruik altyd die korrekte yspak blokke soos aanbeveel deur die vervaardiger.
- Vul die yspak blok met kraanwater tot by die vullyn.
- Verserker dat die yspak blok styf toe gedraai is om te verhoed dat dit lek.
- Gebruik yspak blok, koel blokke en warm blokke volgens die vervaardiger se aanbeveling.
- Volg die verpakkingsinstruksies op die binnekant van die deksel streng vir entstof, yspak blokke, koel blokke en warm blokke
- Plaas altyd die laag skuim materiaal bo-op die yspak blokke en sorg dat die deksel dig toegemaak is.

INSTANDHOUDING INSTRUKSIES

- Moet nie die koelhouer vir lang tye aan direkte sonlig blootstel nie.
- Hou die interne en eksterne oppervlak van die koelhouer droog en skoon as dit nie in gebruik is nie.
- Hou alle metaal onderdele bedek met n dun laag olie wanneer dit nie gebruik word nie.
- Gebruik yspak blokke, koel blokke, warm blokke volgens die vervaardiger se aanbeveling.
- Indien enige van die elemente (bv. hanvatsel, slotte of skaniere) los wikkkel, moet dit dadelik vasgedraai word.

Nceda ufunde le miyalelo ilandelayo ngononophelo njengoko iqulethe ulwazi olubalulekileyo malunga nokusetyenziswa kunye nokugcinwa kweyunithi yakho.

INDLELA YOKUSEBENZISA

- Soloko usebenzisa iipakethi zomkhenkce ezikhuthazwa nguMinus40
- Gcwalisa iipakethi zomkhenkce ngamanzi wempopo kude kufike ekugqibeleni
- Qinisekisa ukuba ezipakethi zomkhenkce zivalwe kakuhle zaqina ukwenzela zingachitheki
- Soloko uzifaka ngendlela eyiyo imikhenkcezisi njengokuba ubuxelelwe kulendawo ubuthenge kuyo
- Landela imigaqo yokufaka imikhenkcezisi eyahlukeneyo Phakathi wesiciko

UHLOBO LOKUGCINA IBHOKISI

- Gcina umphakathi nomphandle wale bhokisi womile futhi ucocekile ngalo lonke ixesha
- Qinisekisa ukuba uzifaka ngendlela eyiyo izikhenkcezisi zakho ezahlukeneyo nje ngokuchaziweyo kulendawo izenzayo
- Ekuhambeni kwexesha ukuba kukho omonakalo njengokuba iindawo zokubamba ibhokisi zihexhe qinisekisa ukuba uyaziqinisa kwangethuba.



VB07 Vaccine Cooler

Congratulations on your new Minus40 Unit!

This premium product incorporates the latest innovations in cooling technology with a highly durable design. Properly maintained, the unit will provide many years of reliable service.



Temperature monitoring

Ensure the temperature monitoring device(s) is not positioned next to an Ice Pack.