

Please read the following instructions carefully as it contains important information concerning the use and maintenance of your unit.



### USER GUIDE

- Always use the correct ice packs as recommended by Minus40
- Fill ice pack with tap water up to the fill line
- Ensure that ice pack caps are correctly tightened to prevent leakage
- Always load ice packs, cool packs and warm packs in accordance with the manufacturer's recommendation.
- Follow the packing instruction on the Lid interior for vaccine, ice packs, cool packs and warm packs.
- Always place the foam sheet on top of the ice packs and ensure that the lid is closed tightly.

### MAINTENANCE INSTRUCTIONS

- Never expose the cold box to direct sun light for long periods.
- Keep internal and external surface of the cold box dry and clean when it is not in use
- Keep all metal parts coated with a thin film of oil when not in use
- Always load ice packs, cool packs and warm packs in accordance with the manufacturer's recommendation.
- Over a period of time if any fixture (e.g. hinge rod, locks & handles) loosens, it should be tightened immediately.

*Lees die volgende instruksies aandagtig deur aangesien dit belangrike inligting bevat oor die gebruik en instandhouding van u eenheid.*

### VERBRUIKERS HANDLEIDING

- Gebruik altyd die korrekte yspak blokke soos aanbeveel deur die vervaardiger.
- Vul die yspak blok met kraanwater tot by die vullyn.
- Verserker dat die yspak blok styf toe gedraai is om te verhoed dat dit lek.
- Gebruik yspak blok, koel blokke en warm blokke volgens die vervaardiger se aanbeveling.
- Volg die verpakkingsinstruksies op die binnekant van die deksel streng vir entstof, yspak blokke, koel blokke en warm blokke
- Plaas altyd die laag skuim materiaal bo-op die yspak blokke en sorg dat die deksel dig toegemaak is.

### INSTANDHOUDING INSTRUKSIES

- Moet nie die koelhouer vir lang tye aan direkte sonlig blootstel nie.
- Hou die interne en eksterne oppervlak van die koelhouer droog en skoon as dit nie in gebruik is nie.
- Hou alle metaal onderdele bedek met n dun laagie olie wanneer dit nie gebruik word nie.
- Gebruik yspak blokke, koel blokke, warm blokke volgens die vervaardiger se aanbeveling.
- Indien enige van die elemente (bv. hanvatsel, slotte of skaniere) los wikkkel, moet dit dadelik vasgedraai word.

*Nceda ufunde le miyalelo ilandelayo ngononophelo njengoko iqulethe ulwazi olubalulekileyo malunga nokusetyenziswa kunye nokugcinwa kweyunithi yakho.*

### INDLELA YOKUSEBENZISA

- Soloko usebenzisa iipakethi zomkhenkce ezikhuthazwa nguMinus40
- Gcwalisa iipakethi zomkhenkce ngamanzi wempopo kude kufike ekugqibeleni
- Qinisekisa ukuba ezipakethi zomkhenkce zivalwe kakuhle zaqina ukwenzela zingachitheki
- Soloko uzifaka ngendlela eyiyo imikhenkcezisi njengokuba ubuxelelwe kulendawo ubuthenge kuyo
- Landela imigaqo yokufaka imikhenkcezisi eyahlukeneyo Phakathi wesiciko

### UHLOBO LOKUGCINA IBHOKISI

- Gcina umphakathi nomphandle wale bhokisi womile futhi ucocekile ngalo lonke ixesha
- Qinisekisa ukuba uzifaka ngendlela eyiyo izikhenkcezisi zakho ezahlukeneyo nje ngokuchaziweyo kulendawo izenzayo
- Ekuhambeni kwexesha ukuba kukho omonakalo njengokuba iindawo zokubamba ibhokisi zihexhe qinisekisa ukuba uyaziqinisa kwangethuba.

## VB03 Vaccine Cooler

### Congratulations on your new Minus40 Unit!

This premium product incorporates the latest innovations in cooling technology with a highly durable design. Properly maintained, the unit will provide many years of reliable service.



#### Temperature monitoring

Ensure the temperature monitoring device(s) is not positioned next to an Ice Pack.